

Схемы установки штапиков

5106  
5186  
5256  
5257  
5258  
5259  
5260  
5431  
5499  
5530




Рис. 1

5114  
5266  
5267  
5268  
5269




Рис. 2

5267  
5114  
5268  
5269

5107  
5102  
5103  
5270




Рис. 3

